

Door Adjustment (Concealed European Hinge)

Adjusting door gap spacing



Step 1 (Identify the inconsistency in the door spacing)

Consistent door spacing can be achieved by adjusting concealed European style hinges. The door in the photo has a larger gap spacing on the hinge (right) side of the door. To make the door spacing more consistent, see step 2 below.



Step 2 (Adjust the spacing of the door)

Turning the screw (as shown in the circle) counter clockwise will make the gap on the hinge side of the door smaller. Turning the screw clockwise will make the gap on the hinge side larger.



Step 3 (Door spacing complete)

Step two can be repeated until the desired door spacing is achieved, as shown in the photo to the left.

Adjusting door face alignment



Step 1 (Identify the inconsistency in the door face alignment)

Consistent door face alignment can be achieved by adjusting concealed European style hinges. The door in the photo to the left has the face of the door located too far in front of the post. To make the door face more flush with the face of the post, see step 2 below.



Step 2 (Adjust the face alignment of the door)

Turning the screw (as shown in the circle) counter clockwise will loosen the screw (Note: Hold the door firmly when loosening the screw). After the screw is loosened slightly push the hinge inward into the case. Turning the screw clockwise to tighten the screw locking the hinge in place.



Step 3 (Door face alignment complete)

Step two can be repeated as needed until the desired door face alignment is achieved, as shown in the photo to the left.